

Fabric and Leather General Care and Cleaning

To prevent overall soiling, frequent vacuuming or light brushing with a non-metallic brush to remove dust and debris is recommended. Application of aftermarket fabric treatment will void any warranty. Avoid contact with household cleaners/chemicals or skin/hair products. Avoid continuous hours of direct sunlight and heat sources. Where possible, flip and rearrange loose cushions frequently to distribute wear evenly.



Most liquids simply roll off of Crypton and LiveSmart fabrics, or they can be quickly blotted off the surface with a dry towel or sponge. The spot cleaning method of stain removal can be used for most light to medium stains, such as coffee, red wine, crayon, and ketchup. Be careful to brush lightly since fibers can be broken or matted during the cleaning process.

1. Before spot cleaning, blot up liquids on the surface with a clean, soft towel and brush off any loose dirt.
 2. Prepare a cleaning solution of 1/4 tsp mild, enzyme detergent, such as Tide®, Woolite® or Dawn® dishwashing liquid, per 1 cup of lukewarm water.
 3. Apply the cleaning solution using a misting spray bottle. Do NOT oversaturate when applying the cleaning solution.
 4. Work the solution into the affected area by lightly scrubbing the area with a sponge or soft bristle brush. Make sure to work from the outside of the stain inward so as not to spread the stain and rinse your sponge or brush frequently.
 5. Allow cleaning solution to soak into the fabric.
 6. Thoroughly rinse fabric to remove all soap residues, as residues will attract dirt. Blot excess moisture with a clean, soft towel or sponge.
 7. Repeat steps 3-6 as needed.
 8. Allow fabric to air dry.
-



While frequent vacuuming is recommended, please do not use any type of vacuum power brush attachment when vacuuming as this can damage the fabric. Most stains can be removed with baby wipes or most general house cleaners that are NOT solvent based such as Lysol, Oxiclean or Dawn dish detergent. Do not use harsh brushes, machine wash, dry clean, or iron. Revolution is also bleach cleanable using the following instructions:

1. Remove any loose debris and blot stain.
 2. Blot or spray water and bleach solution (1 oz. bleach : 30 oz. water) on the stain and allow solution to soak into fabric (if possible, place a clean towel between the fabric and foam cushion to absorb any excess moisture).
 3. Thoroughly rinse fabric with water until clean.
 4. Allow fabric to air dry.
-

(WS) Water Solvent Cleaner

Spot clean with a mild solvent, an upholstery shampoo or the foam from a mild detergent. When using a solvent or dry cleaning product, follow instructions carefully and clean only in a well ventilated room. Avoid any product that contains carbon tetrachloride or other toxic materials. Do not saturate. Use a professional furniture cleaning service when an overall soiled condition has been reached.

(S) Solvent Cleaner

Spot clean, using a mild water-free solvent or dry cleaning product. Clean only in a well ventilated room and avoid any product containing carbon tetrachloride or other toxic materials. Do not saturate. Do not use water. When cleaning a spill, blot immediately to remove spilled material. Clean spots or stains from the outside to the middle of the affected area to prevent circling. Overall cleaning by a professional furniture cleaning service only is recommended.

(W) Water-Based Cleaner

Spot clean, using the foam only from a water-based cleaning agent such as a mild detergent or non-solvent upholstery shampoo product. Do not over wet. Do not use solvents to spot clean. When cleaning a spill, blot immediately to remove spilled material. Apply foam with a soft brush. Clean spots or stains from the outside to the middle of the affected area to prevent circling. Vacuum when dry. Use a professional furniture cleaning service when an overall soiled condition has been reached.

Leather Care and Cleaning

Frequent vacuuming with a soft, non-metallic brush to remove dust and debris is recommended. Gently wipe away any remaining dust with a clean, white cloth. If necessary, dampen a clean cloth with distilled water. For spills, soak up any liquids immediately with a clean, white cloth. Avoid harsh scrubbing. For stubborn stains, contact a local upholstery cleaning professional or a leather technician. For leather that is dry or cracked, a quality leather conditioner may be appropriate. Please test the product in an inconspicuous spot first and follow the product instructions closely. Avoid contact with household cleaners/chemicals or skin/hair products. Avoid continuous hours of direct sunlight and heat sources. Where possible, rearrange loose cushions frequently to distribute wear evenly.